


Spare Part (Screw)


Adjustment screws



Dimensions(mm)

AJS	G	L	W
AJS-M5	M5x0.8	14	2.5
AJS-M6	M6x1.0	14	3.0
AJS-M8	M8x1.0	14	4.0
AJS-M10	M10x1.0	14	5.0
AJS-M12	M12x1.0	14	6.0
AJS-M16	M16x1.0	14	6.0


Clamping screw



Dimensions(mm)

CS	G	L	W
CS-M8	M8x1.25	14	4.0
CS-M10	M10x1.5	14	5.0

ZERO-FIT setting screw



Dimensions(mm)

ZSS	For	G	L	W
ZSS-M4	ID-6,8	M4x0.7	8	2.0
ZSS-M6	ID-10~32	M6x1.0	8	3.0